IPNVR/AHDVR

Please read this manual thoroughly before use and keep it for future reference













WIZARD:

Language





Edit date/time









Add IP cameras



Automatic IP address change





→ Subnet mask

→ Gateway

→ **admin**

→ **admin**

1st IP address

WEB:



Advance series:
192.168.1.111
Next series:
DHCP

Language

admin

admin



To change the default password

DOWNLOAD:

pro.comelitgroup.com → **DOWNLOAD**

Comelit Advance IP tool



Software Comelit CCTV Manager

COMELIT

APP Comelit CCTV :

COMELIT

GET IT ON Google Play

Download on the App Store

APP COMELIT CCTV:







NVR menu:
Settings → Network → P2P



Full manual

COMELIT®
WITH • YOU • ALWAYS

Via Don Arrigoni, 5
24020 Rovetta (BG) - Italy

www.comelitgroup.com